



Part Description

OLM V1 MT Style Carbon Fiber Side Skirts - 2020+ Supra

Part #: OLMA.70208.3

Application: 2020+ Supra

Questions? Email us at: support@olm.com



Parts List:

- ① Left Side Skirt
- ② Right Side Skirt
- ③ Black Sheet metal screws (x8)
- ④ #8x 1" Self Tapping Screws (x8)
- ⑤ Roll of 3M Style trim tape

Required Tools:

Phillips screwdriver

Optional: Roll of masking tape. Used to help position skirts while mounting.

Installation Instructions:

1 – Park the vehicle on a flat surface. Jack up the vehicle or use a vehicle lift if available.

2 – Along each side of the car under the rocker panel, clean the area thoroughly

3 – Offer up the side skirt to the corresponding side. The skirt will taper down in one direction, this is the front of the skirt. The skirts are molded as such to have a noticeable body line that matches the body line of the rocker molding. Take care to align the skirt as you see fit.

(Optional): Secure temporarily with masking tape, or have an assistant help hold in place.

(Optional) Use the roll of double-sided tape to help adhere the skirt to the underside of the rocker cover. If tape is used, please follow our [3M tape guidelines](#) for best adhesion. [LINK HERE:](https://qrco.de/bcRUqm)
<https://qrco.de/bcRUqm>

4 – Use 2 of the black coated sheet metal screws(3) and a Phillips screwdriver to drive the screws into the forward most, and rearward most holes in the skirt. The screws should self-thread with enough pressure. Take care not to over tighten.

5 – Using 2 of the #8 self-tapping screws(4), secure the middle of the skirt via the 2 smaller holes in the side skirt. Take care to not over tighten.

6 – Repeat steps 2-5 for the opposite side.

7 – Lower the vehicle and enjoy your new side skirts!

Questions or issues?

Please be sure to reach out to us at support@olm.com or contact dealer you purchased from for warranty support!

Revision Log:

4/1/2022 - Creation V1.0